

Notice of change to ip Distributors

Starting June 1, 2013 all ip Distributors will now be fitted with the One-Touch style outlet fitting.

This fitting utilizes the same 6mm connector used on our proven portable EDS systems.

This was accomplished to insure a positive and improved connection from the distributor to the cannula or face mask while eliminating the possibility of breakage of the older bayonet style connector.

The original intent with the Bayonet connector was to create a breakaway from the cannula in the event the aircraft was exited while unintentionally wearing the cannula or facemask. However, through customer feedback we learned that this feature created failure problems with the Bayonet style connector.

The Bayonet style connector is still available upon request.

Regards
MH Oxygen

