**REV** 

**ECO** 

2022-033

Drawn

SGO

Release

2022-11-07

Α

В

С

# **HP/HF Regulator**

#### GENERAL SPECIFICATIONS

Inlet Pressure Rating: 3000 PSI MAX

HP/HF Output (per customer specifications):

psi (Dynamic)

psi (Static)

L/min (Average Open Flow Rate)

Weight: 3.0 Oz. [86 a]

MH p/n 09001-0011-90 (CGA-540 Inlet Nipple) Spare O-ring:

See also: MH document 5SREG-310-xxx

# Installing the Regulator

Seat the inlet nipple of the regulator into the corresponding outlet socket of the cylinder valve and turn the grip nut to engage the valve threads.

Complete the connection by turning the grip nut HAND TIGHT ONLY! DO NOT use a wrench or pliers. Over-tightening will damage the regulator. The integrity of the connection is provided by an o-ring seal and is not dependant on the tightness of the threaded coupling.

Connect the outlet tubing and assemble the remainder of your oxygen system (EDS unit or Flowmeter).

Open the cylinder valve **SLOWLY** (~ 2 turns).

## Removing the Regulator

### DO NOT ATTEMPT TO REMOVE REGULATOR WHILE UNDER PRESSURE

The regulator grip-nut will be difficult to turn while under pressure, and doing so will destroy the regulator inlet O-ring.

Bleed-off internal pressure by first *closing the main cylinder valve* and then disconnecting the outlet tubing from the regulator.

The grip nut should now turn easily **by hand** and the regulator can be removed.




Model 310-006H p/n 00REG-1090-03

**OUTLET TUBING CONNECTION - 4mm/6mm Push-To-Connect Fittings** 

REVISION HISTORY

Customer Drawing - Insert



INSERTING

Push in the tubing


### REMOVING

- 1. Push in the connector collar
- 2. Pull the tube straight back while holding the collar in

**To INSERT TUBING:** Push the tubing into the connector until resistance is felt. then push a little further, about 1/8 inch [3 mm]. Gently tug on the tubing to make sure it is captured.

To REMOVE TUBING: Push the tubing in slightly, then push in the connector collar while pulling gently on the tubing.

When removing tubing, **DO NOT pull on the tubing without pushing in the** collar, as this will likely damage the connector.



**Note:** Alternate right-angle outlet fitting provided.

- Replace installed fitting as preferred.
- Maintain cleanliness for oxygen service.
- No Teflon tape required
- Torque to 20 in-lbs.

**MOUNTAIN HIGH E&S CO.** UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN INCHES. REDMOND, OR. USA DIMENSIONS IN [ ] ARE MILLIMETERS (REF) THIS DOCUMENT AND ALL TECHNICAL DATA HEREON DISCLOSED ARE PROPERTY OF MOUNTAIN HIGH E&S CO. AND SHALL NOT BE USED, RELEASED OR DISCLOSED IN WHOLE OR PART WITHOUT WRITTEN PERMISSION FROM MOUNTAIN HIGH E&S CO. THIS DOCUMENT MUST BE RETURNED TO MOUNTAIN HIGH E&S CO. IMMEDIATELY UPON REQUEST. INTERPRET GD&T PER ASME 14.5 MH 3G Regulator, Single-Stage, NO-Gauge, DWG D THIRD ANGLE SGO CGA-540N x 6mm Axial Tube (HP/HF) [Insert] 2022-09-27 **PROJECTION** CHECKED FAM DWG 5IREG-1090-03 -0 2022-11-04 NUMBER REV. JB SRC 00REG-310-xxx\$-0 00REG-1090-03 2022-11-04 FILE NUMBER NAME DO NOT SCALE HBS DWG FORMAT: DWG Α OF 1 DRAWING SHEET 2022-11-07 ESR-002 Rev H [27] SCALE SIZE 11x8½

Α

В

D

1

2

3

Insert #: 5IREG-1090-03